


LP112 Quick Guide



The time of day is automatically set and this unit has linked times for both circuits.

How to set up required ON/OFF times for Heating and Hot Water

- Press SET button to display "SET PROG"
- Press YES button to display "ON 6:30 AM"
- Press buttons - or + to alter the first ON time
- Press SET button to display "OFF 8:30 AM"
- Press buttons - or + to alter the first OFF time
- Press SET button to display "ON 12:00 PM"
- Press buttons - or + to alter the second ON time
- Press SET button to display "OFF 12:00 PM"
- Press buttons - or + to alter the second OFF time
- Press SET button to display "ON 4:30 PM"
- Press buttons - or + to alter the third ON time
- Press SET button to display "OFF 10:30 PM"
- Press buttons - or + to alter the third OFF time

You have now set your HEATING and HOT WATER TIMES

PRESSING THE SET BUTTON, ONE MORE TIME AFTER PROGRAMMING, SETS THE PROGRAMMER TO AUTOMATIC OPERATION

Operating Modes

- Press SELECT Button for Hot Water
 - Press SELECT Button for Central Heating
- OFF = Continuously OFF
TIMED = Switching ON/OFF as programmed

ONCE = ON once from 1st ON to LAST OFF

ON = Continuously ON

The time of day is automatically set and this unit has linked times for both circuits• You can temporarily override the normal switching times by pushing the button marked "ADVANCE". When in timed mode this button switches "ON" to "OFF" or "OFF" to "ON" as you require, but the normal programme switching times will not be permanently affected.